

MOBILE8 MOBILE STAND ASSEMBLY

Please ensure to read instructions fully before assembly. Remove all contents from boxes before assembly.

Step 1: WHEELS

Place base on protective surface. The long ends of the base are the front of the trolley. The brake wheels can be attached to either the front or the back of the trolley. Attach all 6 wheels using the M12 nyloc nuts.

Step 2: ATTACHING UPRIGHT

Remove backing plate from upright using philips head screwdriver. Set aside backing plate and screws for later use. Stand upright over base lining up the holes. Using the 4 x M8x30 bolts, 4 x spring washers, and 4 x M8 nuts attach and fasten the upright to the base.

Step 3: SHELF (optional)

Using the 2 x M6x16 philips head screws attach the shelf to the upright.

Step 4: ATTACHING MOUNTING PLATE

Using the 4 x M8x20 bolts and 4 x M8 spring washers attach the mounting plate to the stand upright at the desired position. There are 3 positions to select from.

Step 5: ATTACHING TOUCHSCREEN

Lift touchscreen onto the stand.
The brackets that fit over the mounting plate are already attached to the touchscreen.
The mobile stand is now ready to use.



For any technical support on stand assembly please contact ABI on 02 9938 6866.

Supplied By: Audio Visual Enginee